

Rod End Dust Boot

Model: Universal

Part #: 98012

- Qty. 1 Rod End Dust Boot



Installation Tips: Insert the Threaded Shaft of the Rod end through one of the Boot Misalignment Holes and then through the threaded shaft hole.



Pull the boot up and over the head of the rod end and align Boot Holes to Rod End Holes. Take caution of install and do not use any lube. The boot will stretch enough for install.

